


Startfreq: 0.100000 MHz; Stopfreq: 50.000000 MHz; Stepwidth: 50.000 kHz

Samples: 999; Interrupt: 0 uS



;no_label

SWR min : 99.90 51.250000

SWR max : 1.00 0.100000
